

# Lantronix PremierWave EN

## Instructions to add python support to an PremierWave EN

This document describes the procedure to add python support to PremierWave EN with firmware version v8.0.0.0.

1. Take the backup of existing device configuration (with export secrets options selected). This can be done via the Web Manger or by using the CLI. Please refer to the user guide for detailed steps.
2. Using firmware upgrade mechanisms documented in the user guide upload the **premierwave\_en\_8\_0\_0\_0R12\_python.rom** to the XC HSPA+ device.